

**NOTES:**

- 1. INSTALL ALL EQUIPMENT PER ELECTRICAL CODES AND OBTAIN PROPER INSPECTIONS.
- 2. OBTAIN PROPER PERMITS FROM SAN JUAN COUNTY PUBLIC WORKS DEPARTMENT FOR ALL INSTALLATIONS ALONG COUNTY] ROAD RIGHT OF WAY.
- 3. ELECTRICAL INSPECTOR MUST APPROVE AND TAG INSTALLATION PRIOR TO OPALCO INSTALLING METER AND CONNECTING WIRES.
- 3. ALL METER BASES SHALL BE APPROVED BY OPALCO AND MUST HAVE A SINGLE SERVICE DISCONNECT THAT INCLUDES OVERCURRENT PROTECTION.

PLAN VIEW

