


NOTES:

1. INSTALL ALL EQUIPMENT PER ELECTRICAL CODES AND OBTAIN PROPER INSPECTIONS.
2. OBTAIN PROPER PERMITS FROM SAN JUAN COUNTY PUBLIC WORKS DEPARTMENT FOR ALL INSTALLATIONS ALONG COUNTY ROAD RIGHT OF WAY.
3. ELECTRICAL INSPECTOR MUST APPROVE AND TAG INTALLATION PRIOR TO OPALCO INSTALLING METER AND CONNECTING WIRES.
3. ALL METER BASES SHALL BE APPROVED BY OPALCO AND MUST HAVE A SINGLE SERVICE DISCONNECT THAT INCLUDES OVERCURRENT PROTECTION.



PLAN VIEW